



Mark V Locating System

Operator's Manual



DCI Headquarters
19625 62nd Ave. S., Suite B-103
Kent, Washington 98032 USA
Tel 425 251 0559/800 288 3610 *Fax* 253 395 2800
E-mail DCI@digital-control.com www.digitrak.com

DCI Europe

Kurmainzer Strasse 56
D-97836 Bischbrunn
Germany
Tel +49(0) 9394 990 990
Fax +49(0) 9394 990 999
DCI.Europe@digital-control.com

DCI India

SCO # 259, Sector 44-C
Chandigarh (UT) 160 047
Punjab, India
Tel +91(0) 172 464 0444
Fax +91(0) 172 464 0999
DCI.India@digital-control.com

DCI China

No. 41, Lane 500, Xingle Road
Minhang District
Shanghai P.R.C. 201107
Tel +86(0) 21 6432 5186
Fax +86(0) 21 6432 5187
DCI.China@digital-control.com

DCI Australia

2/9 Frinton Street
Southport, Queensland 4215
Australia
Tel +61(0) 7 5531 4283
Fax +61(0) 7 5531 2617
DCI.Australia@digital-control.com

DCI Russia

420059 Pavlyukhina Street
104, Kazan
Russia
Tel +7 843 277 52 22
Fax +7 843 277 52 07
DCI.Russia@digital-control.com

3-5000-00-E1

© 2001-2006 by Digital Control Incorporated. All rights reserved. September 2006 Edition.

Trademarks

The DCI logo, CableLink[®], DataLog[®], DigiTrak[®], Eclipse[®], iGPS[®], Intuitive[®], *look-ahead*[®], SST[®], *target-in-the-box*[®], and *Target Steering*[®] are U.S. registered trademarks and DucTrak[™], FasTrak[™], SuperCell[™], L_T[™], TeleLock[™], and TensiTrak[™] are trademarks of Digital Control Incorporated.

Patents

The DigiTrak[®] Locating System is covered by one or more of the following U.S. Patents: 5,155,442; 5,337,002; 5,444,382; 5,633,589; 5,698,981; 5,726,359; 5,764,062; 5,767,678; 5,878,824; 5,926,025; 5,933,008; 5,990,682; 6,002,258; 6,008,651; 6,014,026; 6,035,951; 6,057,687; 6,066,955; 6,160,401; 6,232,780; 6,396,275; 6,400,159; 6,525,538; 6,559,646; 6,593,745; 6,677,768; 6,693,429; 6,756,783; 6,756,784; 6,838,882; 6,924,645; 6,954,073; 7,015,697; 7,049,820; 7,061,244. Sale of a DigiTrak[®] Receiver does not convey a license under any patents covering the DigiTrak[®] Transmitter or underground drill housing. Other patents pending.

Limited Warranty

All products manufactured and sold by Digital Control Incorporated (DCI) are subject to the terms of a Limited Warranty. A copy of the Limited Warranty is included with your DigiTrak[®] Locating System; it can also be obtained by contacting DCI Customer Service, 800-288-3610 or 425-251-0559, or by connecting to DCI's web site, www.digitrak.com.

Important Notice

All statements, technical information, and recommendations related to the products of DCI are based on information believed to be reliable, but the accuracy or completeness thereof is not warranted. Before utilizing any DCI product, the user should determine the suitability of the product for its intended use. All statements herein refer to DCI products as delivered by DCI and do not apply to any user customizations not authorized by DCI nor to any third-party products. Nothing herein shall constitute any warranty by DCI nor will anything herein be deemed to modify the terms of DCI's existing limited warranty applicable to all DCI products.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Rules of the Federal Communications Commission. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the DigiTrak Receiver.
- Increase the separation between the problematic equipment and the DigiTrak Receiver.
- Connect the equipment into an outlet on a different circuit.
- Consult the dealer for help.


Changes or modifications to the DCI equipment not expressly approved and carried out by DCI will void the user's limited warranty and the FCC's authorization to operate the equipment.


Table of Contents


SAFETY PRECAUTIONS AND WARNINGS.....	4
INTRODUCTION.....	5
ON/OFF.....	5
DISPLAY SYMBOLS.....	6
GENERAL OPERATION.....	7
PROCEDURE FOR CHANGING TRANSMITTER FREQUENCY.....	7
RECEIVER DISPLAY MENU FUNCTIONS.....	8
Ultrasonic.....	9
DataLog.....	9
Power.....	10
Frequency.....	11
Telemetry.....	11
Backlight.....	12
1-Pt Calibration.....	12
2-Pt Calibration.....	15
Selftest.....	17
Depth Units.....	17
Pitch Units.....	18
Hour Meter.....	18
LOCATING INSTRUCTIONS.....	19
Handling the Receiver.....	19
Marking Locate Positions.....	19
Locating the Transmitter.....	19
Finding the FLP.....	20
Finding the Tool and the LL.....	21
Confirmation of Exact Heading and Tool Position.....	22
Finding the RLP.....	23
REMOTE DISPLAY.....	24
Main Information Screen.....	24
Menu Options.....	26
Power On/Off.....	26
Telemetry Channel Selections.....	26
Backlight On/Off.....	26
Hour Meter.....	26
Remote Steering Instructions.....	27
DataLog Function.....	27
APPENDIX: DigiTrak Mark III Directional Drilling Locating System Operator's Manual.....	29

Safety Precautions and Warnings


IMPORTANT NOTE: All operators must read and understand the precautions and warnings given below and listed in the *DigiTrak Mark III Directional Drilling Locating System Operator's Manual*.

 Serious injury or death can result if underground drilling equipment makes contact with an underground utility such as a high-voltage electrical cable or a natural gas line.

 Substantial property damage and liability can result if underground drilling equipment makes contact with an underground utility such as a telephone, fiber-optic, water, or sewer line.

 Work slowdown and cost overruns can occur if drilling operators do not use the drilling or locating equipment correctly to obtain proper performance.

- Directional drilling operators **MUST** at all times:
 - Understand the safe and proper operation of drilling and locating equipment, including the use of ground mats and proper grounding procedures.
 - Ensure that all underground utilities have been located, exposed, and marked accurately prior to drilling.
 - Wear protective safety clothing such as dielectric boots, gloves, hard-hats, high-visibility vests and safety glasses.
 - Locate and track the drill head accurately and correctly during drilling.
 - Comply with state and local governmental regulations (e.g., OSHA).
 - Follow all other safety procedures.
- Carefully review this manual and the *DigiTrak Mark III Operator's Manual* to ensure you know how to operate the DigiTrak System properly to obtain accurate depth, pitch, roll, and locate points.
- Prior to the start of each drilling run, test the DigiTrak System with the Transmitter inside the drill head to confirm that it is operating properly.
- Regularly test system calibration while drilling using the ultrasonic function. Always test calibration after you have stopped drilling for any length of time.
- Test system for on-site signal interference. Background noise must be *below* 150, and signal strength must be at least 250 points *above* background noise during all locating operations.

 The DigiTrak equipment is not explosion-proof and should never be used near flammable or explosive substances.

REMEMBER: If you are having difficulty on the job, call DCI (800-288-3610 or 425-251-0559), and we'll attempt to help you solve the problem.

Introduction


The DigiTrak Mark V Locating System is a dual-frequency locating system with operating frequencies at 32.77 and 1.52 kHz. The 32.77-kHz frequency is the standard frequency used by most DigiTrak transmitters. The lower frequency is provided to reduce the effects of passive interference, such as wire mesh or rebar. The frequency can be changed during drilling or setup.

Locating the drill head is streamlined with the Mark V graphic display, which guides you in positioning a target (or a line) in a box on the display window to locate the transmitter in the drill head. You can also locate using the plus/minus signs, as on earlier DigiTrak models. The DigiTrak Mark V system uses the same NiCad battery packs and battery chargers as the Mark III system.


This manual gives information and instructions for the DigiTrak Mark V Locating System. Many of the principles are the same as in the previous DigiTrak systems, so we frequently recommend in this manual that you refer to the *DigiTrak Mark III Directional Drilling Locating System Operator's Manual* to understand how to best operate the system—we have provided a copy of this manual with your Mark V manual. If you need a copy of the *Mark III Operator's Manual*, please call Digital Control Incorporated (DCI) at 800-288-3610 or 425-251-0559.

On/Off


On – To turn the Mark V receiver on, click the trigger once. You will then see the locating screen. The display symbols that appear on the locating screen, as shown below, are described in the next section (see “Display Symbols” section below).



Locating Screen

Off – To turn the unit off, you must first access the menu choices. Click the trigger until you reach the power on/off menu , then hold the trigger in during the countdown from 3 to 0 to shut the receiver off. (See “Receiver Display Menu Functions” section below for more information on the power on/off menu.)

Display Symbols



Telemetry Channel Setting – Shows the current channel setting for the receiver. The receiver must be set to the same channel as the remote display. There are four channel settings (1, 2, 3, 4) and an Off setting.



Locating Icon – Represents a bird's-eye view of the receiver. This icon is referred to as the "box" when using the *target-in-the-box* and *line-in-the-box* locating techniques.



Target – Represents the front and rear locate points (FLP and RLP). When the receiver is positioned directly above a locate point, the target will be in the box.



Line – Represents locate line (LL). When the receiver is positioned directly above the LL, the line will be in the box. The LL also allows for off-track locating when access over the tool is limited (see *DigiTrak Mark III Operator's Manual*).



Plus/Minus Locating Indicator – The plus or minus sign in front of the signal strength value is used to guide the operator in finding the locate points (FLP and RLP) and the locate line (LL).



Signal Strength – Displays the amount of signal from the transmitter. The signal strength scale ranges from 0 to 999, where 0 indicates no signal and 999 indicates signal saturation (receiver and transmitter are very close).




Transmitter Battery – Depicts the battery status of the transmitter.



Transmitter Temperature – Shows temperature status of transmitter. An arrow pointing up next to the thermometer indicates increasing temperature; an arrow pointing down indicates decreasing temperature. A digital temperature reading is displayed below the clock whenever the trigger is held in.




Receiver Battery – Depicts the battery status of the receiver.



Transmitter Pitch – Shows the inclination of the transmitter (tool), displayed either in percent slope or degrees. The pitch value is shown with the drill tool indicator behind it; the indicator will point up for positive pitch and down for negative pitch. Note the smaller superscripted "0" after the "5" in this example. This smaller number shows pitch in tenths of a percent (0.1%) when using sensitive-pitch transmitters.



Pitch/Roll Update Indicator - The dot in the center of the clock should blink every 1.25 seconds, indicating that current pitch, roll, battery and temperature information is being received from the transmitter.



Transmitter Roll – The clock shows the 12 roll positions of the transmitter (tool).



Frequency Indicator – Represents the frequency setting for the receiver as either 1⁵², 32⁷⁷, or search mode. The frequency setting can be viewed from the menu mode or upon release of a held trigger.

General Operation

When you first turn on the Mark V receiver, you will briefly see numbers that represent the firmware in your receiver. After the firmware version, you will see the frequency setting of the receiver, either 1⁵² or 32⁷⁷ (for 1.52 kHz or 32.77 kHz). You will then see the locating screen.

To access the menu functions, you simply **click the trigger**; each trigger click advances you to the next menu function. Each menu has a countdown sequence. To change a menu setting, you **hold the trigger in** while the counter goes down to 0. Once the counter reaches 0, release the trigger and you will hear three confirmation beeps indicating that the menu setting has been changed. The display will then go back to the locating screen.

During locating, to display the transmitter temperature and depth or predicted depth, you **hold the trigger in**. While locating you also need to **hold the trigger in** for 1 second at one of the three locate points: the front or rear locate point (FLP or RLP) or the locate line (LL). This is necessary to lock in on a reference signal strength so that the receiver knows where it is with respect to the transmitter. Note that the receiver frequency setting will briefly display upon release of a held trigger.

The receiver and transmitter must be set to the same frequency. The receiver and transmitter frequency settings can be changed during drilling or while the drill head is above ground. The receiver also has a search mode setting that allows it to automatically switch to the same frequency as the transmitter. For instructions on how to change the receiver frequency setting, see the "FREQUENCY" menu under the "Receiver Display Menu Functions" section. To change the transmitter frequency, see "Procedure for Changing Transmitter Frequency" below.

Procedure for Changing Transmitter Frequency

Three methods are given in this section for changing the transmitter frequency. When using any of these methods, DCI recommends that you first set the receiver frequency to search mode so that it will automatically switch to the frequency of the transmitter. Then, when the transmitter frequency is changed, the receiver will beep three times as confirmation that the transmitter frequency has changed.

Changing Transmitter Frequency Above Ground

1. Place the transmitter in a horizontal position and wait 10 seconds.
2. Place the transmitter in a vertical position with the battery end down and wait 10 seconds.
3. Place the transmitter in a horizontal position; the frequency change should occur in about 10 seconds.

Changing Transmitter Frequency Below Ground

1. Stop the rotation of the transmitter for 10 seconds.
2. Slowly roll the transmitter for 10 seconds (no more than three revolutions).
3. Do a fast roll for 10 seconds then stop; the frequency change should occur in about 10 seconds.


Changing Transmitter Frequency at Startup

1. To start the transmitter at the 32.77-kHz frequency, hold the transmitter vertical with the battery end down and insert the batteries.
2. To start the transmitter at the 1.52-kHz frequency, hold the transmitter vertical with the battery end up and insert the batteries.

NOTE: If the signal strength appears to be very low (e.g., less than 200 points at 5 ft/1.5 m), verify that the transmitter and receiver are set at the same frequency.

Receiver Display Menu Functions

Each of the receiver display menus is described in this section along with instructions for how to change the menu settings. The menus are listed in the order that they appear on the front label of the receiver (see figure below), starting with the ultrasonic menu. The locating mode is the standard default display that you will see when you turn on the receiver.



Receiver Display Menus as Shown on Front Label

ULTRASONIC




This display menu allows you to take an ultrasonic (height-above-ground) measurement.

1. Click the trigger to advance to the ultrasonic menu.
2. Hold the trigger in while holding the receiver steady through the countdown sequence from 2 to 0.
3. When the counter reaches 0, you will hear three confirmation beeps and the ultrasonic height will be displayed along with a checkmark at the bottom of the display.
4. Release the trigger to return to the locating screen.




Ultrasonic Menu Screen



Successful Ultrasonic Measurement

NOTE: If the receiver is less than 12 in. (30 cm) above the ground or sitting on the ground or if the ultrasonic function is not operating properly, an ultrasonic reading of 0 will be displayed, you will hear two long tones, and a crossed check mark will appear at the bottom of the display.



Display Showing Zero (0) Ultrasonic Measurement

DATALOG



This display menu allows you to record a DataLog reading. The procedure sends information to the remote display at the drill rig for recording by the DataLog module. The drill operator must push the "record" button on the DataLog module before a DataLog reading can be recorded. Please also refer to the *DataLog Operator's Manual*.

NOTE: The DataLog menu only appears when the telemetry system is on.

1. Click the trigger to access the DataLog menu.
2. Hold the trigger in while holding the receiver level and steady through the countdown sequence from 3 to 0.
3. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display, indicating that a reading has been sent back to the DataLog module.
4. Release the trigger to return to the locating screen.
5. The remote display will also sound three confirmation beeps when it receives the receiver's signal, and the LCD reading on the DataLog module will be incremented by one count. If the DataLog unit fails to increment one count, the above steps must be repeated.



DataLog Display Menu

POWER



This display menu allows you to turn off the receiver power.

1. Click the trigger to advance to the power menu.
2. Hold the trigger in through the countdown sequence from 3 to 0.



Power Off Screen

3. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display.
4. Release the trigger and the unit will shut off.

FREQUENCY



This display menu allows you to change the receiver frequency. The procedure below describes how to observe the three different frequency setting options and how to change to the desired frequency.

1. Click the trigger to advance to the frequency menu.
2. One of the three options will be displayed (1^{52} , 32^{77} , or search mode, which is indicated by an alternating display of 1^{52} and 32^{77}).
3. Hold in the trigger through the countdown sequence from 2 to 0.
4. Three quick beeps indicate that the setting has been changed.
5. While still holding the trigger in, the receiver will cycle through the three possible settings.
6. Release the trigger when the desired setting is displayed.




Frequency Setting Screen

TELEMETRY



This display menu allows you to change the telemetry channel setting. This is the channel that the receiver uses to communicate with the remote display. The two must be set to the same channel.

1. Click the trigger to advance to the telemetry menu, where the current channel setting is displayed.
2. Hold the trigger in through the countdown sequence from 2 to 0.



Telemetry Channel Setting

3. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display.

4. While still holding the trigger in, the channel settings will cycle slowly through all five settings—Off, 1, 2, 3, 4.
5. Release the trigger when the correct setting is displayed, and you will return to the locating screen.

BACKLIGHT



This display menu allows you to turn on or off the display backlight.

1. Click the trigger to advance to the backlight menu; a light bulb will appear on the display. If the backlight is on, the bulb will be lit up; if it is off, the bulb will appear unlit.
2. Hold the trigger in through the countdown sequence from 2 to 0.



Backlight Is Turned Off



Backlight Is Turned On

3. When the counter reaches 0, you will hear three confirmation beeps and the light bulb will either light up as the backlight comes on or it will become unlit and the backlight will turn off.
4. Release the trigger to return to the locating screen.

NOTE: The backlight automatically comes on for a few seconds at startup, then it defaults to the off setting, even if you have reset it previously.

1-PT CALIBRATION



This display menu allows you to calibrate the receiver using the 1-point calibration procedure. To ensure correct depth readings for dual-frequency operation, you must calibrate the receiver in both frequencies. This requires that you calibrate twice—first at one frequency, then at the other frequency. The transmitter and receiver frequency settings must be set to match during each calibration procedure. For instructions on how to change the transmitter frequency, see the “Procedure for Changing Transmitter Frequency” section. To change the receiver frequency setting, see the “FREQUENCY” menu description above.

The 1-point calibration procedure is performed with the transmitter in the tool using either of two methods, as described later in this section. DCI does not recommend calibrating every day, but you should verify the receiver’s depth readings at several locations using a tape measure.


Calibration is necessary prior to first-time use and when any of the following occur:

- The transmitter is changed.
- The receiver is changed.
- The housing/drill tool is changed.

Do not calibrate if:

- You are within 10 ft (3 m) of metal structures, such as steel pipe, chain link fence, metal siding, construction equipment or automobiles.
- The receiver is over rebar or underground utilities.
- The receiver is in the vicinity of excessive electrical interference.
- The transmitter is not installed into the housing.
- The transmitter is not turned on.

The 1-point calibration menu display appears as follows:




1-Point Calibration Screen

Use either procedure given below to calibrate using the 1-point calibration technique.

Procedure for 1-Point Calibration Using Method 1


1. Using a tape measure, place the receiver on the ground parallel to the transmitter (in drill head) so that the distance from the centerline of the transmitter to the inside edge of the receiver is 10 ft 5 in. (3.18 m), as shown in the sketch given below.



1-Point Calibration – Method 1

2. Click the trigger to advance to the 1-point calibration screen.
3. Hold the trigger in while holding the receiver steady through the countdown sequence from 5 to 0.
4. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display to indicate a successful calibration has been conducted.

5. Release the trigger to return to the locating screen. You must now verify the calibration by checking depth readings at three locations.
6. To verify calibration, place the receiver on the ground parallel to the transmitter so that the distance from the centerline of the transmitter to the inside edge of the receiver measures a given amount on the tape measure; in the example shown in the sketch below, a distance of 6 ft 5 in. (1.96 m) is used. Due to the position of the depth antennas in the receiver, you must add a 5-in. (13-cm) allowance to the distance you intend to check.




Verifying Calibration – Method 1

7. Pull in the trigger to view the depth display, which in our example reads 6 ft (1.83 m).* Note that the depth shown will be the measured distance minus the 5-in. (13-cm) allowance.
8. Repeat the above two steps in at least two more locations.

Procedure for 1-Point Calibration Using Method 2


1. Using a tape measure, place the receiver on the ground on its side so that the distance from the centerline of the transmitter to the bottom of the receiver measures 10 ft (3.05 m), as shown in the sketch given below.



1-Point Calibration – Method 2

*Depth tolerance is 5%; thus, at a distance of 6 ft (1.83 m), the error tolerance is 3.6 in. (9 cm).

2. Click the trigger to advance to the 1-point calibration screen.
3. Hold the trigger in while holding the receiver steady through the countdown sequence from 5 to 0.
4. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display to indicate a successful calibration has been conducted.
5. Release the trigger to return to the locating screen. You must now verify the calibration by checking depth readings at three locations.
6. To verify calibration, place the receiver on the ground on its side so that the distance from the centerline of the transmitter to the bottom of the receiver measures a given amount on the tape measure; in the example shown in the sketch below, a distance of 6 ft (1.83 m) is used.



Verifying Calibration – Method 2

7. Pull in the trigger to view the depth display, which in our example reads 6 ft (1.83 m).* Note that the depth shown will match the measured distance. You do not need to add the 5-in. (13-cm) antenna allowance using this method; however, it can be difficult to view the display for depth readings with the receiver on its side.
8. Repeat the above two steps in at least two more locations.

2-PT CALIBRATION



This display menu allows you to calibrate the receiver with the transmitter in the ground using a 2-point calibration procedure. The receiver and transmitter must be turned on, and the receiver must be held directly over the transmitter and at least 12 in. (30 cm) above the ground. The pitch of the transmitter needs to be less than $\pm 15\%$ for the calibration to be accurate. During the 2-point calibration procedure, the receiver must be raised straight up at least 20 in. (51 cm)—be sure to hold the receiver level and in the same plane with the transmitter.


*Depth tolerance is 5%; thus, at a distance of 6 ft (1.83 m), the error tolerance is 3.6 in. (9 cm).

1. Click the trigger to advance to the 2-point calibration menu.



2-Point Calibration Screen – First Point

2. Hold the trigger in while holding the receiver level and steady through the countdown sequence from 5 to 0.
3. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display.
4. Release the trigger, and the display will show the receiver (side view) with P2 on the display and the countdown will be restarted at 5.



2-Point Calibration Screen – Second Point

5. Raise the receiver straight up at least 20 in. (51 cm), and then hold the trigger in.
6. When the counter reaches 0, you will hear three confirmation beeps and will see a checkmark at the bottom of the display to indicate a successful calibration has been conducted.
7. Release the trigger to return to the locating screen.
8. The 2-point procedure may need to be completed a few times to get a good calibration.
9. Refer to the *DigiTrak Mark III Directional Drilling Locating System Operator's Manual* (Receiver Section, under "Calibrating the Receiver") for instructions on how to verify a proper 2-point calibration.

SELFTEST



This display menu allows you to conduct a self-diagnostic test on the receiver. This test must be conducted in an interference-free area with no active transmitters within range.

1. Click the trigger to advance to the selftest menu.
2. Hold the trigger in through the countdown sequence from 2 to 0, and then release the trigger.
3. When the counter reaches 0, there will be a pause and then you will hear three confirmation beeps and will see a checkmark at the bottom of the display, unless a fault is detected. If a fault is detected, you will see Err displayed along with an error code indicating the nature of the problem (for example, the 001 error code indicates that there is background noise or a transmitter is on). Before continuing, you must troubleshoot the problem or retest in a different area.



Selftest Menu Display



Selftest Error Screen

DEPTH UNITS



This display menu allows you to set the Mark V system to display values (depth and temperature) in either English (inches or ft/in. and °F) or metric (m/cm and °C) units.

1. Click the trigger to advance to the depth units menu. The display will indicate the current setting.
2. Hold the trigger in through the countdown sequence from 3 to 0.
3. When the counter reaches 0, you will hear three confirmation beeps and will see the unit setting change and a checkmark appear at the bottom of the display.
4. Release the trigger to return to the locating screen.




Depth Units Display Menu

PITCH UNITS



This display menu allows you to set the Mark V system to display pitch values in either degrees or percent of slope.

1. Click the trigger to advance to the pitch units menu. The display will indicate the current setting.
2. Hold the trigger in through the countdown sequence from 3 to 0.
3. When the counter reaches 0, you will hear three confirmation beeps and will see the unit setting change and a checkmark appear at the bottom of the display.
4. Release the trigger to return to the locating screen.




Pitch Units Display Menu

HR METER



This display menu allows you to view the actual run time for the Mark V receiver.

1. Click the trigger to advance to the hour meter menu.
2. The hour meter will display the run time in hours, minutes, and seconds, and the hand on the clock will be rotating to count down 5-second increments. (You do not need to hold the trigger in.)
3. The display will return to the locating screen when the trigger is clicked once.



Hour Meter Display

NOTE: The hour meter is useful when measuring transmitter lithium battery usage.

Locating Instructions


Handling the Receiver

IMPORTANT NOTE: It is critical that you hold the receiver correctly to obtain accurate readings. You must hold the receiver **level at all times** and maintain a **constant height-above-ground distance**.

Marking Locate Positions

The front and rear locate points (FLP and RLP) and the locate line (LL) must be found and accurately marked during the locating procedure. To mark a locate position after you have found it, stand with the receiver level immediately above the locate point. Look down the vertical axis that runs through the center of the display to project a plumb line to the ground. The point where this plumb line hits the ground is the location that you should mark.

HINT: If you mark the FLP and the RLP, and then find the LL, you can determine the exact location of the transmitter/tool. It will be immediately below the point where the line connecting the FLP and the RLP intersects the LL. For complete information on the FLP, RLP, and LL, see the *DigiTrak Mark III Directional Drilling Locating System Operator's Manual*.




Plumb Line for Marking Locate Points

Locating the Transmitter


With the DigiTrak Mark V, you can locate the transmitter/tool *and* its heading while it moves, whether standing in front of it, behind it, *or* toward the side. You can also locate the tool either facing toward or away from the drill rig.

The following technique guides you to the tool while standing out in front of it, facing the drill rig. This is the recommended method for locating. As you continue to drill or as the bore path curves, you may be facing the last marked locate point rather than the drill rig.


The first position to find is the front locate point or FLP. The FLP gives you the heading of the tool and the predicted tool depth. The FLP's distance ahead of the tool is dependent upon the tool's depth and pitch; the deeper the tool, the further in front the FLP will be. The FLP is represented as a target  on the receiver's display.

Finding the FLP

1. Stand out in front of the tool (facing the drill) at a distance approximately 2 times the assumed depth.
2. Hold the trigger in for 1 second and release to lock in the signal, then begin walking toward the drill.
3. As you approach the FLP, the target appears in the top left corner of the display and the signal strength increases.




Target in Top Left Corner



Target Moving Toward the Box


4. Continue to walk forward until the target moves into the tracking icon (box). Note that the "+" sign changes to a "-", like it does with the Mark III system.



Target in the Box

5. Turn the receiver 90° to the tool's direction, and again center the target in the box by moving the receiver forward or backward as needed. This is the FLP, which is where the tool will end up if it does not get a steering command.
6. With the target in the box, hold the trigger in for at least 1 second to lock in the signal. During this time, you will see the predicted depth (with an arrow pointing down to a target ahead of the transmitter) and the ultrasonic height. The predicted depth is the depth the tool will be at when it reaches this point (the FLP) if you do not give a steering command.

Arrow pointing to target indicates the target is in the box and the receiver is above the FLP or the RLP. If there is not an arrow, then the reading is the slant distance to the transmitter.




Transmitter temperature replaces pitch reading when trigger is held in.

Predicted Depth Screen


7. Mark the location directly below the display screen as the FLP.
8. Release the trigger to return to the locating screen.

Finding the Tool and the LL

1. At the FLP, turn again to face the tool (and drill) and walk forward toward the last rod locate point.
2. Note that the LL appears in the top left of the display.
3. Walk forward and the LL moves closer to the box.
4. Center the LL in the box. Note that the "-" sign changes to a "+" sign, like it does with the Mark III system.



LL Moving Toward the Box




Line in the Box

5. Hold the trigger in to see the depth display. Note the ultrasonic setting to verify a correct height-above-ground measurement.

NOTE: The arrow that appears below the depth measurement and that points to the transmitter also appears on the remote display when a depth reading is taken.

Arrow pointing to tool head indicates the line is in the box and the receiver is above the transmitter or the LL. If there is not an arrow, then the reading is the slant distance to the transmitter.



Transmitter temperature replaces pitch reading when trigger is held in.


Depth Screen

6. Mark this location as the LL. You should now be standing above the tool.
7. Release the trigger and you will briefly see the receiver frequency (see figure below) before the display returns to the locating screen.




Receiver Frequency Display After Releasing Held Trigger

Confirmation of Exact Heading and Tool Position

Like the FLP, there is a point behind the transmitter called the rear locate point or RLP. When the FLP and RLP are connected, they make a line that represents the transmitter's heading. Where this line intersects the LL is the position of the tool. Using the locate points and the LL to find the tool is more reliable and efficient than using the peak signal. The RLP is represented as a target  on the receiver's display.


Finding the RLP

1. While standing above the tool still facing the drill, continue walking toward the drill; the target will appear in the top left corner of the display and the signal strength will decrease.



Target in Top Left Corner

2. Walk forward until the target moves into the box. Note that the "+" sign changes to a "-" sign, like it does with the Mark III system.



Target in the Box

3. Turn the receiver 90° to the tool's direction and again put the target in the box by moving the receiver forward or backward as needed.
4. Mark this location as the RLP.
5. Connect the RLP to the FLP by a line. This line represents the transmitter/tool's heading.


NOTE: If you hold the trigger in at the RLP, you will see a predicted depth reading. This depth is only valid at the FLP and must be ignored at the RLP. The receiver cannot discern between the RLP and the FLP.

Remote Display

The Mark V remote display screen is configured in the same way as that on the receiver, and it uses the same display symbols. The remote display, however, has a main information screen and then only four menu options (power on/off, telemetry channel selection, backlight on/off, and hour meter). The main information screen is described below, and then the menu options are explained. Specific information on remote steering with the Mark V remote display and its use with a DataLog mapping system is also included.

Main Information Screen


The main information screen shown below is displayed when you turn on the Mark V remote display unit. The on/off button on the remote works similarly to the trigger on the receiver. The speaker on the remote warns the operator if the transmitter's temperature is increasing—temperature increases are accompanied by tones from the speaker to indicate that appropriate and immediate attention is required. The speaker also emits tones during the DataLog function when a DataLog reading is received.



Front of Mark V Remote Display


The main information screen indicates when the receiver is over the transmitter or the locate line (LL), as shown below. The depth reading has an arrow below it pointing to the transmitter to indicate that the reading is the actual depth of the transmitter or LL rather than the slant distance. If there is not an arrow pointing down from the depth reading (as shown in the above graphic), then the distance is the slant distance.

Arrow pointing to tool head indicates the line is in the box and the receiver is above the transmitter or the LL. If there is not an arrow, then the reading is the slant distance to the transmitter.



Depth Reading When Receiver Is Above Transmitter or LL


By holding in the on/off button for 2 seconds or more, the receiver's frequency setting will display in the bottom left and the transmitter temperature will display in place of the pitch information, as shown below.



Frequency and Temperature Reading with On/Off Button Held In

As shown below, the arrow below the depth reading is pointing to a target in front of the transmitter—this indicates that the receiver has the target in the box and is above the front or rear locate point (FLP or RLP). If the receiver is over the FLP, then the reading is the predicted depth. If there is not an arrow with the depth reading, then the distance is the slant distance to the transmitter.

Arrow pointing to target indicates the target is in the box and the receiver is above the FLP or the RLP. If there is not an arrow, then the reading is the slant distance to the transmitter.



Up or down arrow indicates increasing or decreasing trend in transmitter temperature.


Predicted Depth Reading When Receiver Is Above FLP or RLP

Menu Options

The menu options are accessed in the same way as on the receiver. Click the on/off button to get to the menu screens, and then hold the button in for the countdown.


Power On/Off

With the power on/off menu displayed, as shown in the picture to the right, hold the button in for the countdown sequence from 3 to 0 to turn the unit off.




Telemetry Channel Selections

The telemetry channel menu, shown in the picture on the right, allows you to change the telemetry channel setting. Hold the button in to cycle through the four channel options (1, 2, 3, 4), and release when the desired setting is selected.




Backlight On/Off

At the backlight on/off menu option, shown in the picture on the right, hold the on/off button in to turn the display backlight on or off.



Hour Meter


The hour meter menu option displays the amount of time that the remote display unit has been running (turned on). In the picture on the right, the hour meter shows that the remote display unit has been running for 2,145 hours, 35 minutes, and 12 seconds. Click the on/off button once to exit the hour meter and return to the main information screen.



Remote Steering Instructions

Instructions for using the Mark V system for remote steering are given below. Please refer first to "Remote Steering" under the Remote Display section in the *DigiTrak Mark III Directional Drilling Locating System Operator's Manual* for instructions on how to set up the equipment.

Once the transmitter is lined up with the receiver, the arrow will appear below the depth reading and, when perfectly aligned, the target symbol in the center of the remote steering indicator will blink. If the tool gets off course, then the arrows to the left or right will start flashing, depending on the direction in which it has gone off course. The further the tool goes off course, then the further to the left or right of the target symbol the flashing arrows will be. For example, the arrow to the left of the target symbol will start blinking if the tool deviates to the left, and as it goes further to the left, then the arrows further to the left of the target symbol will be flashing.



Display During Remote Steering When Transmitter Is Aligned with Receiver

DataLog Function

The DigiTrak Mark V remote display unit works differently when using the DataLog function than earlier DigiTrak remote displays. The correct procedure for taking a DataLog reading using the Mark V system is given below. Please also refer to the *DataLog Operator's Manual*.

1. Press the "Write" button on the DataLog module to place the unit in standby mode, which is indicated by a flashing LCD on the DataLog module.
2. At the Mark V receiver, record a DataLog reading (see instructions on page 9).
3. The remote display will sound three confirmation beeps when it receives the DataLog information, and the LCD count on the DataLog module will be incremented by one.

Notes

3-5000-00-E1